



**T5: Slipcase  
Folding Instructions**

The precut pattern of your folder should be placed on the table with the white side facing up.

Fold all the prefluted edges vertically at a 90° angle. (These are the rounded sides)

Bend the double-walled side segments inwards over the edges.

Please pay particular attention to the spigot (double-fold). If necessary, use a Teflon Folder.

Bend the walls of the box inwards and hold them vertically (right-angled).

Holding the side walls vertically, gently insert the rounded flaps (which have been folded) between the double walls of the sides.

When folding, press inwards and downwards towards the base of the box.

Repeat procedure on other side.