



T13: Tucked Clamshell Box Folding Instructions

The precut pattern of your folder should be placed on the table with the white side facing up.

Fold all the prefluted edges vertically to a 90° angle, and then fold back down into a flat position. This will help fold the box & ensure crisp edges.

Bend the walls parallel to the spine to a 90° angle. Now, fold the 2 remaining walls (flap should be folded at -90°, such that it runs parallel to the perpendicular wall). Flaps from perpendicular walls will fold inside the box wall, holding the walls in place.

Now complete folding the 3rd wall. Flaps that were folded -90° in the previous step should be secured inside of this wall.

Place the narrow strip into the spine to reinforce the box.

Finally, fold the lid and closure tab.

TALAS

330 Morgan Ave, Brooklyn NY 11211
tel: 212-219-0770

www.talasonline.com