



T14: Document Storage Box Folding Instructions

The precut pattern of your folder should be placed on the table with the white side facing up.

First, fold the base flaps to 90°, and then fold the whole back side up to a 90° angle.

Then fold the front sides 90°. Now, fold this whole front side up to a 90° angle. Both sides should be fully erected.

Fold the side walls attached to the back wall.

Continue to fold this wall, such that it secures the walls together.

You may now close the box by inserting the lid-flap into the long slit provided.

TALAS

330 Morgan Ave, Brooklyn NY 11211
tel: 212-219-0770

www.talasonline.com